



White Wolf Hex Series

These hexagon shaped marble tiles provide design opportunities that are unique, yet natural and organic in feel. Available in 10mm and 16mm thickness, they were designed to be installed as floor tiles or as a wall covering with a 3D effect.

erth
COVERINGS

Hex Series

Product Information



WHITE WOLF | 06H

PRODUCT DETAILS

Uses	<input type="checkbox"/> FLOOR	<input checked="" type="checkbox"/> INT	<input type="checkbox"/> WALL
Finish	Honed		
Format	8" Hexagon		
Thickness	10mm or 16mm		

COLOUR RANGE

Due to the nature of natural stone, colour may vary between batches. This is standard across the natural stone industry.

NAME	CODE	STONE TYPE
White Wolf	06H-10 / 06H-16	Marble

Beauty
Set in
Stone.

Hex Series Installation Instructions

RECOMMENDED MORTAR

Rapid setting or white mortar is highly recommended.

RECOMMENDED SEALER (only when required)

A professional grade natural stone penetrating sealer may be used on Erth stone veneers.

RECOMMENDED GROUT (only when required)

Un-Sanded Grout should only be used.

FLOOR INSTALLATION

STEP 1

Ensure all surfaces accepting the tile are clean and free of all loose material and dust. Surfaces must be structurally sound and comply with local building codes. Install using the same process as regular floor tiles.

STEP 2

Ensure to clean the surface of the stone using clean water only. Do not allow the mortar to dry on the surface.

STEP 3

Prior to grouting the joints, it is highly recommended that the stone is sufficiently sealed. This will ensure that absorption of the grout colour does not occur as absorption could result in the dis-colouration of the stone. A matte finish penetrating sealer is recommended. Always follow the sealers instructions and test the sealer prior to sealing all the stone.

Beauty
Set in
Stone.

**Erth**
COVERINGS

erthcoverings.com

Hex Series Installation Instructions

WALL INSTALLATION

STEP 1

Ensure all surfaces to be faced are clean and free of all loose material and dust. Surfaces to be faced must be structurally sound and comply with local building codes. Apply starter strips where required and ensure all starter strips are installed perfectly level.

STEP 2

Apply the mortar to the substrate using a minimum 3/8" notched trowel. Apply mortar to the back of each piece of stone using a flat hand trowel. Place the stone in place and ensure proper adhesion is achieved by pressing firmly on the face of the stone. Our Hex Series can be installed with or without grout joints, and with a flat surface or 3D effect. Tiles of different thicknesses can be placed randomly on the wall to achieve a 3D effect. When installing, ensure all mortar is removed from the edges of the tiles prior to installing the adjacent pieces. This will ensure that all adjacent pieces are installed as tight as possible and thus eliminating unsightly gaps.

STEP 3

Where needed, tiles should be cut with a wet saw to ensure accurate and clean cuts. Never mark the surface of the stone with a permanent marker as this will be absorbed by the stone and cannot be removed.

STEP 4

During the installation and after the installation is completed, wipe the surface clean with clean water only, ensuring to remove all mortar and dust from the surface..

STEP 5

Prevent any vibration or hammering of the wall for a period no less than 24 hours after the stone has been applied.

STEP 6

ERTH recommends the use of sealer on all applications susceptible to staining to protect the stone and allow for easy cleaning (especially in high traffic areas). A test sample may be required to determine the desired look .

NOTE:

These installation instructions are intended as a guide only. For further assistance, please contact ErthCoverings at 1 866 657 6606 (Toronto).

Beauty
Set in
Stone.

**Erth**
COVERINGS

erthcoverings.com